

Alpha Clock Five

User Interface Guide



	SNOOZE SET ALARM	ALARM ON/OFF SET TIME		+	-
<i>Press</i>	Snooze	Alarm: On/Off		Brightness: Increase	Brightness: Decrease
<i>Hold</i>	Show alarm time Adjust alarm time, using +/-	Adjust time, using +/-		-	-
<i>Hold pair</i>	Hold these two buttons for 4 seconds: Show firmware version & Enter LED test mode			Hold these two buttons for 2 seconds: Enter (or leave) settings menu	

Settings Menu:

